



AAKAMZ46 系列說明書 AAKCCD46 INSTRUCTION MANUAL

KWC® KIEN WELL TOY INDUSTRIAL CO., LTD
www.kwcgun.com

台南市仁德區義林路168巷89號
NO.89, LN. 168, YILIN RD.,
RENDE DIST., TAINAN CITY
71752, TAIWAN (R.O.C.)
TEL : +886-6-2798175
FAX : +886-6-2798176
sales@kwcgun.com
www.kwcgun.com



操作/OPERATION

安全裝置：保險作用為防止誤扣扳機時而不至於擊發 OPERATING THE TRIGGER SAFETY DEVICE

- ★請務必聽到切換時保險開關的聲音，以確定保險是處於安全而正確的位置。
Make sure to hear the click when switching safety on and off to ensure the safety is at proper position.

保險關閉，可擊發
SAFETY OFF




保險開啟，不可擊發
SAFETY ON



裝彈方法：壓下彈匣卡榫後便可抽出彈匣

LOADING BB: Press magazine release catch to remove magazine.



- A. 將彈匣側蓋往下推開定位。
B. 裝入BB彈(最多205發)。
C. 彈匣滑粒向下推到底，有卡榫可以定位固定住。
D. 請上下左右搖晃彈匣，使BB彈可從彈孔跑出，進入子彈溝槽排列。
E. 每次裝彈可射擊數量為15發

- ★最後將彈匣插入，直到聽到”喀嗒”聲響後才停止。

- A. Open magazine rear cover.
B. Load BB (capacity max 205pcs).
C. Pull magazine follower down and fix it by clamping.
D. In order to filling the BB, please shake magazine gently. Then ammos will flow out from BB stock and place on line for shooting.
E. 15 BB speedload magazine.

- ★Firmly re-insert the loaded magazine back into the grip. You will hear a “Click” indicating the magazine is securely locked in place.

射擊操作 COCKING AND SHOOTING

- A. 將保險推到”射擊時”狀態。
B. 將上蓋往後拉到底，聽到”喀嗒”聲響。
C. 確認上蓋是否確實彈回原來的位置。
(若上蓋未完成回到原來位置而扣引扳機的話，有可能會損壞槍身內部活塞)
D. 扣引扳機後BB彈被發射出去。
E. 若不再繼續發射時，將保險推到”不射擊時”狀態。

- A. Switch safety off.
B. Pull the slide back until you hear a “Click” indication the shot is locked and ready.
C. Make sure that the slide has returned backed to its original position before pulling the trigger.(pulling the trigger before the slide is properly seated will cause internal damage to the air soft gun).
D. Pull the trigger to shoot.
E. Repeat step B for next shot.



- ★向目標射擊之前，請勿將手指放在扳機上！
★Do not pull the trigger except shooting.



⚠ WARNING

此低動能遊戲用槍是針對喜愛射擊運動的消費者所開發。避免因使用方法不正確或改造所發生的故障或事故，請務必詳讀說明書，正確的操作享受愉快的射擊運動。

- 除了發射時外，不要將手指頭掛在板機上。
- 選擇安全與適當標靶
- 在非使用期間，請保持保險關閉且退彈的狀態，就算在非使用狀態，也要如同其已裝彈。
- 如任何的機械產品，槍的保險也可能失效。即使在保險關閉的狀態下也請小心的操作此槍，請勿將槍口對人。
- 千萬不要對堅硬或平坦表面、水面射擊，以避免跳彈。
- 請妥善保管產品在未成年孩童無法伸手取得的場所。
- 每次使用前後都應該檢查擋彈物，假如擋彈物表面有磨損失效或是反彈時請停止使用。
- 請使用高品質BB彈，請勿使用①口徑大於6mm ②表面不平滑的③重複使用過的BB彈④非本說明書指名的發射物。
- 最高的使用及儲藏CO2小鋼瓶環境為50°C (122°F)以內，高溫可能會造成CO2小鋼瓶過熱甚至爆炸。
- 檢查任何掉落之槍枝，以確保未影響其功能。

請務必嚴格遵守 使用說明指導書
For your safety, please read this manual carefully before use.

This airsoft is intended for recreational or training purposes. To prevent improper handling, modification or alteration causing malfunction or accident, please read the owner's manual carefully. Enjoy the pleasant shooting experience by proper operation.

- Do not put your finger on the trigger except shooting.
- Please choose safe and proper target.
- Please always keep the airsoft on safe and unloaded when not using.
- Like all mechanical devices, an airsoft safety can fail. Always handle the airsoft safely even when the safety is “on safe”. Never point the airsoft at any people.
- Avoid ricochet. Never shoot at a hard or flat surface or at water.
- Keep the airsoft out of reach for small children.
- Your backstop should be inspected for wear before and after each use. Discontinue use of the backstop if surface shows signs of failure or ricochet.
- Only use high quality BB. Never use ①BB diameter larger than 6mm ②BB with unsmoothed surface ③reused BB that has been fired ④incorrect projectiles not design for this airsoft.
- Do not expose CO2 cartridges to heat or store them at temperatures above 50°C (122°F). CO2 cartridges may over heat or explode at temperatures above 50°C (122°F).
- Check any gun that has been dropped to ensure that its function has not been affected.

⚠ WARNING 警告

AAKAMZ46 系列 零件表


AAKAMZ46 SERIES PARTS LIST

AAKAMZ46 系列 零件分解圖

AAKAMZ46 SERIES EXPLODED VIEW


★使用玩具槍前，
請務必戴上保護
眼鏡或面罩。

- ★ Always wear eye protection when using airsoft.



★不可攜帶玩具槍
在公共場所行走，
請務必裝在袋子或盒子內。


- ★ Always transport an airsoft in a locked carrying case. Make sure it is unloaded and on safe.



Do not display this pistol in public—it may confuse people and may be a crime.
請不要忘了，雖然自己知道這只是玩具，但不知道的人，會以為這是真槍。

★使用玩具槍前，
請務必詳讀說明
書內容。

★ Read the owner's manual before using the airsoft.




★請不要由槍口向
內探視。

★ To Avoid accidental discharge, do not look directly into the barrel.




★請不要在公開場合使用玩具槍，也請不要拿玩具槍對準人或動物。

- ★ Never brandish or aiming this airsoft at any people or domestic animals. Brandish this airsoft in public is dangerous and may be a crime.




★請確認後再發射BB彈方向，附近無人或動物存在。

★ Always be aware of your surrounding before and during shooting and select a safe area for target practice.




★不可任意改造或加工玩具槍，私自改造加工會造成產品損壞、保固失效，導致使用上不安全，甚至觸法送辦。

★ Disassemble, modify, or alter of your airsoft may cause malfunction, void your warranty and may make it unsafe to use.



NO.	零件名稱	UNIT
P05	槍管接筒	BARREL CONNECTOR
P07	接筒卡榫	CONNECTOR CATCH
P10	彈簧支座	SPRING STOCK
P51	彈匣滑粒	MAGAZINE FOLLOWER
P56	氣缸	CYLINDER
P62	槍管導管	OUTER BARREL
P63	導管卡榫軸套	OUTER BARREL SLEEVE
P64	導管卡榫	BARREL CATCH
P66	氣缸卡榫	CYLINDER CATCH
P67	上蓋後罩	SLIDE REAR CAP
P68	彈匣底座卡榫	MAGAZINE BASE CATCH
P84	彈匣(左)	MAGAZINE(L)
P85	彈匣(右)	MAGAZINE(R)
P86	子彈卡榫	AMMO CATCH
P88	彈匣側蓋	MAGAZINE SLIDE PLATE
P601	槍身本體	FRAME
P603	槍柄	GRIP
P605	扳機	TRIGGER
P606	扳機連桿(右)	TRIGGER BAR(R)
P607	彈匣卡榫	MAGAZINE CATCH
P610	彈匣底座	MAGAZINE BASE
P615	保險(左)	SAFETY(L)
P616	上蓋止動片	SLIDE STOPPER
P636	保險釋放件	SAFETY RELEASE
Z09	活塞	PISTON
Z24	活塞卡榫	PISTON CATCH
Z66	活塞固定座	PISTON BASE
Z601B	擊鐵箱	CHASSIS
Z607	上蓋	SLIDE

NO.	零件名稱	UNIT
R01	活塞迫緊	PISTON PACKING
R06	子彈迫緊	HOP-UP ADJUST
B06	槍管	INNER BARREL
B67	導管卡樺軸	BARREL CATCH PIN
F11	導管配件	OUTER BARREL ACCESSORY
F601	軸(擊鐵箱用)	PIN (CHASSIS)
F603	軸(固定座用)	PIN (PISTON GUIDE)
F605	平頭軸(活塞卡樺用)	PIN (PISTON CATCH)
F705	平頭軸(活塞卡樺用)	PIN (PISTON CATCH)
S02	子彈卡樺壓簧	AMMO CATCH SPRING
S51	彈匣壓簧	MAGAZINE SPRING
S54	活塞壓簧	PISTON SPRING
S603	活塞卡樺扭簧	PISTON CATCH SPRING
S605	槍管導管壓簧	OUTER BARREL SPRING
S606	扳機扭簧	TRIGGER SPRING
S607	導管卡樺扭簧	BARREL CATCH BUTTON
S608	止動片扭簧	SLIDE STOPPER SPRING
S609	扳機連桿(左)	TRIGGER BAR(L)
S611	底座卡樺壓簧	BASE CATCH SPRING
S613	彈匣卡樺線簧	MAGAZINE CATCH SPRING
S614	扳機連桿左扭簧	TRIGGER BAR(L) SPRING
EA023	⊕ 2.3X8束黑	SCREW 2.3X8
E02	⊕ Ⅲ 2.3X6束黑熱螺絲	SCREW 2.3X6
X1	氣缸組件	CYLINDER UNIT
X2	擊鐵箱組件	CHASSIS UNIT



※零件有時為了改良而不經預告變更。
Spare parts may be modified for quality improvement
And such modification may be without advance notice.